



Roto Safe E

E700

Electromechanical multipoint lockings for doors

Contact

Roto Frank
Fenster- und Türtechnologie GmbH
Wilhelm-Frank-Platz 1
70771 Leinfelden-Echterdingen
Germany
Phone +49 711 7598 0
Fax +49 711 7598 253
info@roto-frank.com
www.roto-frank.com

	1	General information	9
	1.1	Version history	9
	1.2	Instructions	9
	1.3	Symbols	10
	1.4	Pictographs	10
	1.5	Abbreviations	11
	1.6	Explanation of terms	11
	1.7	Target groups	11
	1.8	Target groups' obligation to give instructions	12
	1.9	Copyright protection	13
	1.10	Limitation of liability	13
	1.11	Preserving the surface finish	13
	2	Security	15
	2.1	Presentation and structure of warning instructions	15
	2.2	Security levels of warning instructions	15
	2.3	Specific safety information	15
	2.3.1	Batteries	15
	2.4	Stipulated use	16
	2.4.1	Misuse	17
	2.5	Basic safety information	17
	2.5.1	Installation	17
	2.5.2	Use	17
	2.5.3	Ambient conditions	18
	2.6	Operation	19
	3	Information on the product	21
	3.1	Product characteristics	21
	3.2	Functional principle	21
	3.3	Tolerance – height offset	22
	4	Brief instructions	23
	4.1	Installation sequence	23



5	Installation	25
5.1	General information	25
5.1.1	For the fabricator	25
5.2	Screw connections	28
5.2.1	Timber	29
5.2.2	PVC	29
5.2.3	Aluminium	29
5.2.4	Screwdriving recommendations	30
5.3	Force-fit connection	30
5.3.1	Lever-operated espagnolette	31
5.4	Main locks	32
5.4.1	Main lock E700 Backset 35, 40 mm	32
5.4.2	Main lock E700 Backset from 45 mm	36
5.5	Overview of multipoint locks	38
5.6	Double-leafed doors	40
5.6.1	Lever-operated espagnolette, standard	40
5.6.2	Lever-operated espagnolette Plus	41
5.7	Drilling and routing dimensions	43
5.7.1	Leaf	43
5.7.2	Frame	46
5.8	Leaf	49
5.8.1	Predrilling the door lever handle set	49
5.8.2	Turning the latch and trigger unit around	52
5.8.3	Preparing to connect Eneo to the power supply	58
5.8.4	Multipoint lock	59
5.8.5	Lever-operated espagnolette, standard (second opening leaf)	60
5.8.6	Lever-operated espagnolette Plus (second opening leaf)	63
5.8.7	Door lever handle set	65
5.9	Frame	67
5.9.1	Striker strip / striker	67
5.9.2	Variable striker strips	68
5.9.3	Installation	69
5.9.4	Shootbolt protrusion striker	70



6	Accessories	71
6.1	Cable junction	71
6.1.1	Overview of versions	71
6.1.2	Bush and connector	75
6.1.3	Processing instructions	75
6.1.4	Dimensions	76
6.1.5	Drilling and routing dimensions	78
6.1.6	Installation	80
6.1.7	Performance test for cable junction with built-in power supply unit	83
6.1.8	Fault assistance	84
6.1.9	Dismantling	84
6.2	Finger scan	85
6.2.1	Dimensions	85
6.2.2	Routing and drilling dimensions	86
6.2.3	Installation	87
6.2.4	Testing using the autotest function	88
6.2.5	Overview	88
6.2.6	Definitions	89
6.2.7	Calibrating the master fingerprint	90
6.2.8	BioKey® app	90
6.2.9	Calibrating user fingerprints	91
6.2.10	Blocking or approving user fingerprints	92
6.2.11	Reset	92
6.2.12	Changing the master code	92
6.2.13	Opening the door	93
6.2.14	Fault assistance	93
6.3	4in1 access control system	94
6.3.1	Dimensions	94
6.3.2	Routing and drilling dimensions	95
6.3.3	Installation	96
6.3.4	Testing using the autotest function	97
6.3.5	Reset (factory settings)	97
6.3.6	SOREX SmartLock app	97
6.3.7	Fault assistance	98
6.4	Hand-held transmitter	99

6.4.1	Overview	99
6.4.2	Security	99
6.4.3	Calibrating the hand-held transmitter	100
6.4.4	Deleting hand-held transmitters	100
6.4.5	Changing the battery	101
6.4.6	Fault assistance	101



7	Connection diagram	102
7.1	Control Unit	103
7.2	Cable junction without power supply unit	104
7.3	Cable junction with built-in power supply unit	106
7.4	Cable routing	107
7.5	Cable lengths	108



8	Adjustment	109
8.1	Overview	109
8.2	Strikers	109
8.2.1	Latch / deadbolt striker	110
8.2.2	Combination striker	110
8.2.3	Timber	111
8.2.4	PVC	111
8.2.5	Aluminium	111
8.3	Striker strips	112
8.4	Lever-operated espagnolette, standard	112
8.5	Lever-operated espagnolette Plus	112
8.6	Trigger unit	114



9	Commissioning and operation	116
9.1	E700	116
9.1.1	Initial operation of the door	116
9.1.2	Activating / deactivating acoustic signals	118
9.1.3	Fault assistance	119
9.1.4	Acoustic signals	121
9.2	Lever-operated espagnolette, standard	122
9.3	Lever-operated espagnolette Plus	122



10 Technical data 124

10.1	Eneo A	124
10.2	Cable junction	124
10.3	Finger scan	124
10.4	4in1 access control system	125
10.5	Hand-held transmitter	125
10.6	Power supply unit	125



11 Maintenance 126

11.1	Maintenance intervals	126
11.2	Cleaning	127
11.3	Care	128
11.3.1	Lubrication points	128
11.4	Drive unit	129
11.5	Performance test	129
11.5.1	Mechanical-automatic performance test	129
11.5.2	Electrical performance test	131
11.6	Repair	131
11.7	General information	132
11.7.1	For the end customer	132



12 Dismantling 134

12.1	Hardware components	134
------	---------------------	-----



13 Transport 135

13.1	Transporting elements and hardware	135
13.2	Information on transport	136
13.3	Storing the hardware	137



14 Disposal 138

14.1	Disposing of packaging	138
14.2	Disposing of hardware	138
14.3	Batteries	138
14.4	Electronic waste	138



15	Additional information	140
15.1	Product information about E700 – 2AH	140

1 General information

1.1 Version history

Ver- sion	Date	Changes
v0	22/02/2023	Publication
v1	13/04/2023	Classification key in accordance with prEN 15685:2019 → <i>from page 140</i> Torque specified for turning the latch around on the additional lock → <i>from page 52</i>
v2	18/01/2024	Installation instructions restructured Universal magnet not possible, text removed Lever-operated espagnolette, standard added → <i>from page 40</i> 4in1 access control system (new product) → <i>from page 94</i> Turning the trigger unit around adapted → <i>from page 52</i> Adjusting the trigger unit added → <i>from page 114</i>

1.2 Instructions

This manual contains important information, instructions, application diagrams (max. sash sizes and weights) and assembly instructions for the installation, maintenance and operation of hardware.

The information and instructions contained in this document refer to products belonging to the Roto hardware system named on the front page.

All steps must be completed in sequence.

The following documents apply in addition to these instructions:

Catalogue

- Roto Safe catalogue: CTL_86

Installation instructions

- Roto Safe E | Eneo Control Unit: IMO_288
- Connection diagrams: IMO_310

Quick guide

- Power supply unit specifications: SUG_3
- Roto Safe E | Cable junction: SUG_28
- Finger scan: SUG_37
- 4in1 access control system: SUG_43
- Roto Safe E | Eneo – replacing the drive unit: SUG_46

Additional guidelines and directives

- Instructions and information issued by profile manufacturers (e.g. manufacturers of windows and balcony doors),
- The applicable regulations, directives and national laws.

Storing the instructions

These instructions are an important part of the product. The instructions must be stored so that they are always to hand.

Explanation of the markings

The manual uses the following markings for emphasis (e.g. in figures or instructions):

Marking	Meaning
	Optional / alternative components seated in the leaf
	Leaf / components seated in the leaf
	Optional / alternative components seated in the frame
	Frame / components seated in the frame
	Drill holes, routing, screw positions
	Unaffected components / indirectly affected components
	Components, arrows or movements that have just been described
	Item number
[1]	Legend
[A]	Steps



INFO

Any dimensions without a unit in the instructions are given in millimetres (mm). Other units of measurement are clearly indicated by the presence of the differing unit.



INFO

Figures are provided in the right-hand version (DIN 107).

1.3 Symbols

Symbol	Meaning
	First-level list
	Second-level list
	(Cross-)reference
	Result
	Unnumbered step
1.	Numbered step
a.	Numbered second-level step
	Requirement

1.4 Pictographs

Symbol	Meaning
 	Timber
 	PVC
 	Aluminium
	Door



1.5 Abbreviations

Abbreviation	Meaning
A	Amperes
AC	Alternating current
W	Width
CTL	Catalogue
°C	Degrees Celsius
DC	Direct current
H	Height
Hz	Hertz
IMO	Installation instructions
kg	Kilograms
kV	Kilovolts
L	Length
m	Metres
mA	Milliamperes
Max.	Maximum
Min.	At least
mm	Millimetres
mm ²	Square millimetres
ms	Milliseconds
MHz	Megahertz
Nm	Torque in newton metres
SUG	Quick guide
D	Depth
V	Volts
W	Watts

1.6 Explanation of terms

Lock

The term “lock” refers to the deadbolt in the main lock and the additional locks, used to lock the door securely.

Door locked

The term “door locked” means that the door is secured by an unsprung rigid deadbolt that has been pushed out of the main lock, and/or additionally by other additional locks. All locking elements engage in corresponding recesses in the door frame, or striker plates, the lock casing, etc.

1.7 Target groups

The information in this document is directed at the following target groups:

Hardware dealers

The “hardware dealers” target group includes all companies and individuals that purchase hardware from hardware manufacturers for resale, without modifying or further processing the hardware.

Door manufacturers

The “door manufacturers” target group includes all companies and individuals that purchase hardware from hardware manufacturers or hardware dealers and further process the hardware by integrating it in doors.

Building element dealers or installation companies

The “building element dealers or installation companies” target group includes all companies and individuals that purchase doors from door manufacturers for resale and installation in a construction project, without modifying the doors.

Builders

The "builders" target group includes all companies and individuals who place orders for the manufacture of doors for installation in their construction projects.

Qualified electrician

The device may only be assembled, installed, commissioned and maintained by suitably trained electricians with the appropriate qualifications.

The electrician must have read and understood this document, as well as the other applicable document, and must follow the instructions.

The qualified electrician must comply with the national regulations that apply in their country (e.g. DIN VDE 0105, EN 50110) with regard to installation, performance testing, repair and maintenance of electrical products and apply them correctly..

End users

The "end users" target group includes all individuals who use the installed doors.

1.8 Target groups' obligation to give instructions

**INFO**

Each target group must fulfil their obligation to give instructions in full.

Unless specified otherwise in the text below, documents and information can be passed on as a printed document, on a data storage device or via the Internet.

Responsibility of hardware dealers

Hardware dealers must pass the following documents on to the door manufacturer:

- Catalogue
- Installation, maintenance and operation instructions

Responsibility of the door manufacturer

The door manufacturer must pass the following document on to building element dealers or the builder, even if a subcontractor (installation company) is involved:

- Installation, maintenance and operation instructions

They must ensure that the end users are provided with the documents and information intended for them in printed format.

Responsibility of building element dealers / the installation company

Building element dealers must pass the following document on to the builder, even if a subcontractor (installation company) is involved:

- Maintenance and operation instructions

Responsibility of the builder

The builder must hand over the following document to the end user:

- Maintenance and operation instructions

1.9 Copyright protection

The contents of this document are copyright-protected. This content can be used when working with the hardware. Any other use is not permitted without written permission of the manufacturer.

1.10 Limitation of liability

All information and instructions contained in this document have been compiled in consideration of the applicable standards and regulations, the latest developments in technology and many years of knowledge and experience.

The hardware manufacturer assumes no liability for damage caused by:

- Failure to comply with this document and all product-specific documents and other applicable directives (see the chapters entitled "Security" and "Stipulated use").
- Improper use / misuse (see the chapters entitled "Security" and "Stipulated use").
- Insufficient invitation to tender, non-compliance with installation specifications and non-compliance with the application diagrams (where available).
- Increased contamination.

Claims made by third parties against the hardware manufacturer on account of damage resulting from misuse or failure to comply with the obligation to give instructions on the part of hardware dealers, window, door and balcony door manufacturers and building element dealers or the builder are passed on accordingly.

The obligations agreed in the delivery contract, the general terms and conditions, the hardware manufacturer's terms and conditions of delivery and the legal provisions applicable when the contract was concluded shall apply.

The warranty only covers original Roto components.

We reserve the right to make technical changes as part of improvement to performance characteristics and further development.

1.11 Preserving the surface finish



ATTENTION

Surface treatments may cause property damage.

Surface treatments (e.g. painting and varnishing) on elements can damage components or prevent them from working properly.

- ▶ For masking, only use adhesive tape that does not damage the paint coats. Consult the manufacturer if in doubt.
- ▶ Protect components against direct contact with the surface treatment.
- ▶ Protect components against contamination.



ATTENTION

Using incorrect cleaning agents and sealing compounds may cause property damage.

Cleaning agents and sealing compounds may damage the surfaces of components and gaskets.

- ▶ Do not use aggressive or flammable liquids, acidic cleaners or abrasive cleaners.
- ▶ Only use mild, pH-neutral cleaning agents that have been diluted.
- ▶ Apply a thin protective film to the components, for example using a cloth soaked in oil.
- ▶ Avoid aggressive vapours (e.g. produced by formic acid, acetic acid, ammonia, amine compounds, ammonia compounds, aldehyde, carboic acid, chlorine, tannic acid) around the element.
- ▶ Do not use any acetic acid-crosslinking or acid-crosslinking sealing compounds or those with the aforementioned constituents as both direct contact with the sealing compound and its fumes can corrode the surface of the components.



ATTENTION

Contamination may cause property damage.

Contamination prevents components working properly.

- ▶ Remove deposits and contamination caused by construction materials (e.g. plaster, gypsum).
- ▶ Keep components free of deposits and contaminants.



ATTENTION

(Permanently) damp room air may cause property damage.

Damp room air can lead to mould growth and corrosion caused by condensation.

- ▶ Provide adequate ventilation for components, particularly during the construction phase.
- ▶ Intensively air out the room several times per day by opening all elements for approximately 15 minutes. If intensive airing is not an option, place the elements in the tilt position and provide airtight masking inside the room, e.g. if there is fresh screed that cannot be walked on or must not be exposed to draughts. Discharge any humidity present in the room air to the outside using condensation dryers.
- ▶ Establish a ventilation plan for more complex construction projects if necessary.
- ▶ Provide adequate ventilation during holiday periods as well.



2 Security

This manual contains instructions relating to safety. The principal safety information in this chapter includes information and instructions relevant to the safe use or maintaining the safe condition of the product. Warning instructions that relate to handling warn of residual risks and are located before steps that are relevant to safety.

- Follow all of the instructions in order to prevent personal injury and property and environmental damage.

2.1 Presentation and structure of warning instructions

The warning instructions relate to individual actions and are structured as follows with a warning symbol:

	DANGER Nature and source of the danger. Explanation and description of the danger and the implications. <ul style="list-style-type: none">► Measures to take to avert the danger.
--	---

2.2 Security levels of warning instructions

The warning instructions that relate to handling are identified differently according to the severity of the associated danger. The signal words and the associated warning symbols used are clarified below.

	DANGER Immediate risk of death or serious injuries. <ul style="list-style-type: none">► Observe these warning instructions to avoid personal injuries.
--	---

	WARNING Potential risk of death or serious injuries. <ul style="list-style-type: none">► Observe these warning instructions to avoid personal injuries.
--	--

	CAUTION Risk of injuries <ul style="list-style-type: none">► Observe these warning instructions to avoid personal injuries.
--	--

	ATTENTION Reference to property or environmental damage. <ul style="list-style-type: none">► Observe these warning instructions to avoid property or environmental damage.
--	---

2.3 Specific safety information

2.3.1 Batteries

Handling batteries incorrectly poses an immediate risk of death or serious injuries.

Handling batteries incorrectly can lead to hazardous situations or property damage.

- Store batteries out of reach of children, as they might play with the batteries and could swallow them.

If a battery has been swallowed, consult a doctor immediately.

- ▶ Do not expose the battery to moisture, fire or high temperatures.
- ▶ Avoid connecting the positive (+) and negative terminals (–) (for example avoid wrapping the battery in aluminium foil). Risk of short-circuit!
- ▶ No not recharge or open batteries.
- ▶ Use only the type of batteries recommended in these instructions.
- ▶ Do not throw the battery into open flames. Risk of explosion!

2.4 Stipulated use

E700

The multipoint locking described in these instructions is designed for installation in doors. The multipoint locking is only intended for further processing on doors for vertical installation made from the materials described in these instructions. The multipoint locking opens, closes and locks doors.

Hand-held transmitter

The hand-held transmitter is only permitted for use with electromechanical multipoint lockings from Roto Frank Fenster- und Türtechnologie GmbH.

With its range of up to 10 metres, the transmitter makes it possible to conveniently open doors remotely.

There is no security against faults caused by other devices that are operated properly in the same frequency range.

Finger scan with app

The finger scan makes it possible to open electromechanical multipoint lockings using a fingerprint. Configuration and user management take place via the app.

4in1 access control system

The 4in1 access control system makes opening the door simple. The door can be opened by entering a PIN code or using a fingerprint, Bluetooth-capable smartphone or RFID-capable medium.

The 4in1 access control system can be used with all Eneo locks.

Cable junction

The cable junctions can be used for supplying power to electromechanical multipoint lockings.

Eneo Control Unit

The Eneo Control Unit is used to check for proper operation. This way, the door manufacturer can pass a tested door on to the next tradesperson involved.

Eneo power supply unit

The Eneo power supply unit provides the electronic components with a reliable supply of the energy they need.

The following applies to all products:

The stipulated use also includes compliance with all information contained in the product-specific documentation, such as:

- These installation, maintenance and operation instructions
- Product catalogues
- Information, specifications from profile manufacturers (e.g. light metal profiles, etc.)
- Applicable national laws and directives.



2.4.1 Misuse

Any use and processing of the products that goes beyond or differs from the stipulated use is considered misuse and can lead to hazardous situations.



WARNING

Misuse may pose a risk of death!

Misuse and incorrect installation of hardware can lead to serious injuries.

- ▶ Only use hardware combinations that have been approved by the hardware manufacturer.
- ▶ Only use original accessories or those that have been approved by the hardware manufacturer.
- ▶ Note the product-related documentation → *from page 9*.

2.5 Basic safety information

The following hazards may arise when handling the product:

2.5.1 Installation

Incorrect installation poses an immediate risk of death or serious injuries.

Incorrect installation or assembly of hardware can lead to hazardous situations or property damage. Depending on the height of the fall, this can result in serious to life-threatening injuries and glass breakage.

- ▶ Only use hardware combinations that have been approved by the hardware manufacturer.
- ▶ Only use original accessories or those that have been approved by the hardware manufacturer.
- ▶ Always have installation performed by a specialist company.

Heavy loads pose a risk of injury.

Lifting and carrying heavy loads may lead to injuries in the event of a fall or physical overexertion.

- ▶ Note the applicable accident prevention regulations.
- ▶ Transport heavy loads with two people and use suitable transportation means (such as an industrial truck).

Physical overexertion may be harmful to health.

Moving heavy loads for extended periods leads to physical injury in the long term.

- ▶ When carrying and lifting by hand, comply with a maximum weight of 25 kg for men and 10 kg for women.
- ▶ Carry and lift even small loads with an ergonomically correct posture.

2.5.2 Use

Falls from open windows and balcony doors present an immediate risk of death and pose the risk of serious injuries.

Opened sashes of windows and balcony doors create a danger zone. Depending on the height of the fall, this can result in serious to life-threatening injuries and glass breakage.

- ▶ Take care when in the vicinity of open windows and balcony doors.

- ▶ Keep children and anyone unable to understand the risks away from the hazardous area.

Trapping body parts in the opening between sash and frame may lead to serious injuries.

Gripping between the sash and frame when closing windows and balcony doors poses the risk of crushing injuries.

- ▶ When closing windows and balcony doors, never grip between the sash and frame and always exercise caution.
- ▶ Keep children and anyone unable to understand the risks away from the hazardous area.

Opening and closing leaves improperly poses the risk of injury and property damage.

Incorrect opening and closing of leaves can result in serious injuries and substantial property damage.

- ▶ When moving the sash, ensure that it will not slam against the frame or other leaves once fully opened or closed.
- ▶ Ensure that the sash is slowly guided by hand throughout its entire movement range, until it has been brought into a fully closed or opening position.
- ▶ When closing a sash and locking the hardware, the gasket counter force must be overcome.

Misuse poses a risk of injury and property damage.

Misuse can lead to hazardous situations and may destroy the hardware, frame materials or other individual components within the windows or balcony doors.

- ▶ Do not introduce any obstacles in the opening area between the frame and window or balcony door sashes.
- ▶ Do not place additional loads on windows and balcony door sashes.
- ▶ Refrain from intentionally or uncontrollably slamming or pushing the window or balcony door sash against the window reveal or the opening restrictor.

Improper maintenance poses the potential risk of injury and property damage.

Windows and balcony doors, including the hardware, require expert maintenance (care, cleaning, maintenance and inspection) in order to guarantee their proper condition and safe use.

- ▶ Keep the hardware free of deposits and contaminants.
- ▶ Carry out care and cleaning tasks as specified in these instructions.
- ▶ Always have regular maintenance, adjustment and repair work carried out by a specialist company.

2.5.3 Ambient conditions

Physical and chemical influences may result in property damage.

Hardware components can be permanently damaged in a saline, aggressive or corrosive environment to the point that they can no longer function.

- ▶ Do not use the hardware components in a saline, aggressive or corrosive environment.
- ▶ Carry out care and cleaning tasks as specified in these instructions.
- ▶ Corrosion protection must be inspected by an authorised specialist company as part of regular maintenance work.

Moisture may cause property damage.

Depending on the outside temperature, relative humidity of the room air and installation situation of the windows and balcony doors, a temporary build-up of condensation may occur. This can lead to corrosion on the hardware




and mould growth on the frame or wall. Ambient conditions that are too damp, particularly during the construction phase, can lead to timber elements warping.



- ▶ Avoid preventing the circulation of air (e.g. due to deep reveals, curtains and unfavourable positioning of heaters or the like).
- ▶ Intensively air out the room several times per day.
Open all windows and balcony doors for approximately 15 minutes so that the air in the room can be completely replaced.
- ▶ Provide adequate ventilation during holiday periods as well.
- ▶ Create a ventilation plan for construction projects if necessary.

2.6 Operation

The safety symbols and markings and the associated warning instructions explained below apply to the safe operation of doors.

Safety symbols and markings

Symbol	Meaning
	<p>Trapping body parts in the opening between leaf and frame may lead to serious injuries.</p> <p>When closing doors, never grip between the leaf and frame and always exercise caution.</p> <p>Keep children and anyone unable to understand the risks away from the hazardous area.</p>
	<p>Placing additional loads on the leaf may lead to minor injuries and property damage.</p> <p>Avoid placing additional loads on the leaf.</p>
	<p>Opening and closing the leaf in an uncontrolled manner may result in minor injuries and property damage.</p> <p>Ensure that the leaf is slowly guided by hand throughout its entire movement range, until it has been brought into a fully closed or opening position.</p> <p>Avoid exposing the open leaf to wind.</p> <p>Close doors in windy and draughty conditions.</p>

Symbol	Meaning
	<p>Introducing obstacles into the opening between leaf and frame may result in minor injuries and property damage.</p> <p>Avoid introducing obstacles into the opening between leaf and frame.</p>
	<p>Pressing the leaf against the edge of an opening (reveal) may pose a risk of minor injuries and cause property damage.</p> <p>Avoid pressing the leaf against the edge of an opening (reveal).</p>



3 Information on the product

3.1 Product characteristics

Security

- deadbolt in the main lock extends automatically
- VdS-certified burglary inhibition (in the pipeline)
- automatic power wedge and deadbolt are push-back safeguarded without using the key

Comfort

- automatic closing without using the key
- quiet and powerful motor for effortless opening
- latches ensure consistent gasket compression and prevent door warping
- Plug&Play connection for simple and error-free installation

Efficiency

- Standardised locking patterns for reduced logistics and installation effort
- Profile-related frame components for efficient installation
- Latch can be turned around when installed for simple conversion on the construction site
- Eneo Control Unit for easily checking functionality

Design

- Door designs up to 3000 mm for creative freedom
- durable and scratch-resistant surfaces for a high-quality appearance in the long term
- backsets from 35 to 80 mm for a high level of flexibility

Quality

- certified continuous operation characteristics for permanent functional safety
- corrosion-resistant surfaces for a safe investment

3.2 Functional principle

Locking the door

Close the leaf.

- ▶ All of the automatic power wedges and the deadbolt extend.
→ 9.1.1.1 “Mechanical-automatic performance test” from page 116

Unlocking the door from the outside

A pull handle or push bar must be fitted to the outside of the leaf.

Depending on the access control system available, unlocking can be triggered by hand-held transmitter, finger scan, 4in1 access control system, etc. Unlocking using the key is possible at all times.

Once locked using the key, the door lever handle is blocked from the inside and the door cannot be opened electronically. A key must be used in order to unlock the door.

Unlocking the door from the inside

Eneo A can be unlocked using the door lever handle.


Once locked using the key, the door lever handle is blocked from the inside and the door cannot be opened using the door lever handle. It is necessary to first use the key to unblock the door lever handle.



INFO

Installation of a knob cylinder is not recommended.

3.3 Tolerance – height offset



- [1] Functional clearance (distance between striker / front edge of striker strip and front edge of faceplate)
- [2] Striker / striker strip
- [3] Faceplate
- [4] Height offset between centre of lock and centre of striker (markings present)




4 Brief instructions

4.1 Installation sequence

	Step	Note	Page reference
Leaf	Route the profile for the multipoint lock.		→ from page 43
	Route the profile for the cable junction.		→ from page 78
	Route the profile for the accessories.	Finger scan 4in1 access control system	→ from page 86 → from page 95
	Predrill the door lever handle set.		→ from page 49
	Turn the latch around if required.		→ from page 52
	Install the cable junction.		→ from page 80
	Lay the cable.		
	Install and connect the access control system.	Finger scan 4in1 access control system	→ from page 87 → from page 96
	Connect the drive unit.		→ from page 58
	Install the multipoint lock.		→ from page 59
	Install the lever-operated espagnolette (standard, Plus) on the second opening leaf.	Only for double-leaf doors	→ from page 40
	Install the door lever handle set.		→ from page 65
Frame	Route the profile for the frame components.		→ from page 46
	Route the profile for the cable junction.		→ from page 78
	Install the cable junction.		→ from page 80
	Install the striker strip or strikers and any electrical openers required.		→ from page 67
	Install the top shootbolt protrusion striker.	Only for double-leaf doors	→ from page 70
	Install the bottom shootbolt protrusion striker.	Only for double-leaf doors	
Final acceptance	Make the necessary adjustments.		→ from page 109
	Lubricate the hardware.		→ from page 128
	Carry out a performance test on the multipoint lock.		→ from page 116
	Carry out a performance test on the cable junction.		→ from page 118
	Performance test on access control system	Finger scan 4in1 access control system	→ from page 88 → from page 97

Example



[1] Multipoint lock → *from page 38*

[2] Cable junction with cable → *from page 71*

[3] Access control system

Finger scan → *from page 85*


4in1 access control system → *from page 94*




5 Installation

5.1 General information


5.1.1 For the fabricator






Turn the screws in straight so that no distortion can occur. Do not use stainless-steel screws on the Roto Sil surface. Use stainless-steel screws on stainless-steel components.



Do not drill through the lock area of the door leaf when the lock is installed (e.g. for protective hardware).



Manufacture door designs so that it is ensured that the locks always operate properly. Observe the axis dimension.



INFO

When an original cylinder is not installed, only unlock the door using the Roto universal access key. Alternatively, use an extractor handle.



INFO

Install the profile cylinder or round cylinder without subjecting it to stress (align it 90° to the leaf).



INFO

Install the long plates and escutcheons without subjecting them to stress (align them 90° to the leaf).




ATTENTION



Contamination may cause property damage.

Contamination may get behind the floating mullion and block the multipoint locking system.

- Do not wipe contamination in the upper area of the sash (e.g. plaster, gypsum) towards the floating mullion.



[1] Grease



Lubricate the latches and trigger unit at least once a year.



ATTENTION

Using incorrect lubricants may cause property damage.

Substandard lubricants can prevent the hardware from working properly.

- ▶ Use high-quality lubricants.
- ▶ Only use resin-free and acid-free lubricants.
- ▶ Use appropriate lubricant in more challenging climatic conditions. Note the manufacturer specifications.



ATTENTION

Incorrect lubrication may cause property damage!

Lubricants in the main lock and additional locks may prevent them from working properly.

- ▶ Only lubricate the latches and trigger unit.

During transport, secure the leaf against the frame using suitable supports (run-up blocks, wedges, etc.).

Do not remove the cylinder fixing, which is a transport safety mechanism, until you are about to install the profile cylinder.

Do not carry the leaf by the door lever handle.

5.2 Screw connections



ATTENTION

Improper screw fixings may cause property damage.

Improper screw fixings may damage the components and the element as a whole, and stop them from working properly.

- ▶ Unless stated otherwise, turn screws in straight.
- ▶ Tighten screw heads until they are flush with the surface.
- ▶ Do not over-tighten screws. Note the torque. Choose a torque that will not deform the hardware and profile. Define profile-specific torques on the basis of the demo assembly.
- ▶ Use the recommended screws.
- ▶ Select the length of the screws according to the profiles used.



ATTENTION

Using incorrect screw material may cause property damage.

Using the wrong screws may damage the components.

- ▶ Only use galvanised zinc-plated and passivated steel screws.
- ▶ Use screws with additional sealing in more challenging climatic conditions.
- ▶ Use stainless-steel screws on stainless-steel components only.
- ▶ For aluminium components, use screws made of steel (coated with zinc-nickel or zinc flakes) or stainless steel.

General information

- During installation and screwdriving work, observe the specifications provided by the profile manufacturer; contact the profile manufacturer if necessary.
- Use the recommended screws.
- Select the length of the screws according to the profiles used.
- Ensure that the hardware components are adequately secured; contact the screw manufacturer if necessary.



5.2.1 Timber


Fasten hardware components using electrogalvanised and passivated steel fixing screws. Use fixing screws with additional sealing in more challenging climatic conditions.

Fixing screws for timber strikers



INFO

It can be seen from each individual timber striker whether the fixing screws have to be turned in straight or at a 15° angle.



Choose screws for timber strikers with a 15° angle:

[A] Screw diameter

[B] Maximum possible head diameter

[C] Maximum possible screw length

5.2.2 PVC



ATTENTION

Incorrect screw connections may cause property damage.

Short screws will not pass through two walls in the steel reinforcement and will therefore not hold. The multipoint lock can be pulled out of the leaf if it is not screwed through two walls.

- Select the length of the screws so that they will hold in the two walls of the steel reinforcement.

Fasten hardware components using electrogalvanised and passivated steel fixing screws. Use fixing screws with additional sealing in more challenging climatic conditions.

5.2.3 Aluminium



ATTENTION

Improper screw connections may cause property damage.

The multipoint locking can be pulled out of the profile if it is not screwed down correctly.

- Select the length of the screws so that they will hold in the aluminium profile.

If necessary, insert additional aluminium profiles or use rivet nuts.




INFO


If rivet nuts are used instead of screws, use countersunk nuts.

5.2.4 Screwdriving recommendations


Timber



PVC



Aluminium



5.3 Force-fit connection




INFO

Force-fit connections are formed by screwing down components A and B so that forces and movements are transferred without loss.

Couplable hardware components always require a force-fit connection.



5.3.1 Lever-operated espagnolette




Assignment	Description
[1]	Component A
[2]	Retaining clip
[3]	Rivet
[4]	Faceplate link
[5]	Component A toothed segment
[6]	Component B
[7]	Component B toothed segment
[8]	Screw

5.4 Main locks

5.4.1 Main lock E700 | Backset 35, 40 mm

Profile cylinder





Assignment	Meaning	Value
[D]	Backset	35 and 40 mm
[E]	Distance	92 mm
[M]	Centre of spindle-receiver to centre of main lock	22 mm
[N]	Centre of spindle-receiver to lower edge of main lock	125 mm
[S]	Centre of main lock	–
[U]	Deadbolt protrusion with 35 mm backset	16 mm
	Deadbolt protrusion with 40 mm backset	20 mm
[X]	Latch (can be turned around)	–
[Y]	Deadbolt	–



INFO


The backset and dimensions for the latch and deadbolt protrusion refer to a 3 mm faceplate thickness.

Installation

Main locks

Main lock E700 | Backset 35, 40 mm

Round cylinder





Assignment	Meaning	Value
[D]	Backset	35 and 40 mm
[E]	Distance	94 mm
[M]	Centre of spindle-receiver to centre of main lock	22 mm
[N]	Centre of spindle-receiver to lower edge of main lock	125 mm
[S]	Centre of main lock	–
[U]	Deadbolt protrusion with 35 mm backset	16 mm
	Deadbolt protrusion with 40 mm backset	20 mm
[X]	Latch (can be turned around)	–
[Y]	Deadbolt	–



INFO


The backset and dimensions for the latch and deadbolt protrusion refer to a 3 mm faceplate thickness.

Main locks

Main lock E700| Backset from 45 mm

5.4.2 Main lock E700| Backset from 45 mm

Profile cylinder






Assignment	Meaning	Value
[D]	Backset	45 to 80 mm
[E]	Distance	92 mm
[M]	Centre of spindle-receiver to centre of main lock	22 mm
[N]	Centre of spindle-receiver to lower edge of main lock	125 mm
[S]	Centre of main lock	–
[U]	Deadbolt protrusion	20 mm
[X]	Latch (can be turned around)	–
[Y]	Deadbolt	–



INFO

The backset and dimensions for the latch and deadbolt protrusion refer to a 3 mm faceplate thickness.

Round cylinder



Assignment	Meaning	Value
[D]	Backset	45 to 80 mm
[E]	Distance	94 mm
[M]	Centre of spindle-receiver to centre of main lock	22 mm
[N]	Centre of spindle-receiver to lower edge of main lock	125 mm
[S]	Centre of main lock	–
[U]	Deadbolt protrusion	20 mm
[X]	Latch (can be turned around)	–
[Y]	Deadbolt	–



INFO

The backset and dimensions for the latch and deadbolt protrusion refer to a 3 mm faceplate thickness.

5.5 Overview of multipoint locks

Possible additional lock versions

Abbreviation	Meaning
2AH	2 automatic power wedges


Possible striker strip versions (combination locks)

Abbreviation	Meaning
2C	2 combination locks



INFO


The standard striker strips and strikers are used for the E700.



Frame		Leaf	
[1]	Striker strip	[5]	Flat faceplate
[2]	Combination striker	[6]	U-shaped faceplate
[3]	Electrical opener / deadbolt striker	[7]	Additional lock (AH)
[4]	Latch / deadbolt striker	[8]	Main lock E700
		[9]	Drive unit

5.6 Double-leafed doors

5.6.1 Lever-operated espagnolette, standard




Assignment	Meaning
[1]	Connector component for lever-operated espagnolette, standard
[2]	Lever-operated espagnolette, standard
[3]	Second opening leaf
[4]	First opening leaf
[5]	Flat faceplate
[6]	U-shaped faceplate
[7]	Additional lock (AH)
[8]	Main lock E700
[9]	Drive unit



Assignment	Meaning
[10]	Extension 600
[11]	Extension 800

5.6.2 Lever-operated espagnolette Plus



Assignment	Meaning
[1]	Connector component for lever-operated espagnolette Plus
[2]	Lever-operated espagnolette Plus
[3]	Second opening leaf
[4]	First opening leaf
[5]	Flat faceplate
[6]	U-shaped faceplate
[7]	Additional lock (AH)

Installation

Double-leafed doors

Lever-operated espagnolette Plus


Assignment	Meaning
[8]	Main lock E700
[9]	Drive unit
[10]	Extension 468
[11]	Extension 768



5.7 Drilling and routing dimensions

5.7.1 Leaf

5.7.1.1 Routing



- [1] Faceplate marking
- [D] Backset
- [E] Distance
- [M] Centre of spindle-receiver to centre of main lock
- [RZ] Round cylinder
- [X] Cropping range


Handle height at various distances

[G]	1020
-----	------

Handle height at various distances	
[E]	92 / 94
[M]	22

Pattern	A	B	C	F	K	M	O	[X]
V02/01	2200	738	632	438	260	998	1630	400
V02/03	2200	738	752	438	260	998	1750	300
V02/05	1900	738	382	438	260	998	1380	400
V02/07	2400	738	982	438	260	998	1980	200

5.7.1.2 Lever-operated espagnolette, standard




- [1] Faceplate marking
- [2] Routing axis



[3] Lever-operated espagnolette, standard

5.7.1.3 Lever-operated espagnolette Plus



[1] Faceplate marking


[2] Routing axis

[3] Lever-operated espagnolette Plus

[4] Centre of routing

5.7.2 Frame

5.7.2.1 Additional lockings (AH)



- [1] Faceplate marking
- [2] Routing axis
- [3] Combination striker
- [4] Latch / deadbolt striker
- [5] Striker strip

► Carry out the routing work as shown in the drawing.



INFO

The routing refers to PVC and aluminium strikers.
Request the routing drawing for timber strikers.



INFO

The routing depth depends on the leg height on the striker.
Example – combination striker:

- Striker height = 24.5 mm
- Leg height = 7 mm
- Min. routing depth = 17.5 mm




INFO

The routing axis depends on the profile.

Pattern	B	C
V02/01	738	632
V02/03	738	752
V02/05	738	382
V02/07	738	982


5.7.2.2 Top shootbolt protrusion



[1] Centre of lever-operated espagnolette


5.7.2.3 Hinge retaining mechanism

Hinge retaining mechanism cam



[1] Faceplate marking

Hinge retaining mechanism set





5.8 Leaf

5.8.1 Predrilling the door lever handle set



PRECONDITION

Drilling and routing work carried out on the leaf → *from page 38*.




ATTENTION

Incorrect drilling methods may cause property damage!


If holes are drilled in the lock area with the multipoint lock inserted, the lock may be damaged.

- Remove the multipoint lock before drilling.

1. Insert the multipoint lock [1] into the leaf.



2. Insert the square spindle [2] and profile cylinder [3] in predrilled holes in the leaf → *from page 43*.




Installation


Leaf

Predrilling the door lever handle set

3. Position the drilling jig [4] from the relevant manufacturer and mark the drill holes [5].




4. Remove the square spindle and profile cylinder.






5. Remove the multipoint lock.



6. Drill the holes [6].



7. Deburr the drill holes and remove chips.

**INFO**

A pull handle or push bar must be fitted to the outside of the door.

**INFO**

A round escutcheon can be used from a backset of 35 mm.

5.8.2 Turning the latch and trigger unit around



ATTENTION

Turning the latch around incorrectly may cause property damage!

If the latch is installed incorrectly, the lock may be damaged.

- ▶ Only turn the latch around in the vertical lock position.
- ▶ Only turn the latch around when the lock is unlocked.
- ▶ Do not use the door lever handle or key when turning the latch around.

The latch can be turned around to use the main lock for DIN left or DIN right doors.

The latch can be turned around when installed.


5.8.2.1 Turning the latch around on the main lock



PRECONDITION


The lock is unlocked.

1. Push the pin [1] (Ø max. 3 mm) into the inspection opening.






2. Push the pin down slightly so that the latch blocking device [2] disengages.



3. Remove the latch [3].




Installation


Leaf

Turning the latch and trigger unit around

4. Turn the latch 180°.




5. Insert the latch straight into the shaft and push it in until it clicks into place.






5.8.2.2 Turning the latch around on the additional lock

1. Undo the screw [1].



2. Remove the latch [2].




Installation

Leaf


Turning the latch and trigger unit around

3. Turn the latch 180°.



4. Insert the latch straight into the shaft and push it in until it clicks into place.

5. Tighten the screw to 1.2 Nm.






5.8.2.3 Turning the trigger unit



PRECONDITION


The trigger unit has previously been triggered.

1. Push the pin [1] (Ø max. 3 mm) into the inspection opening.




2. Push the pin down slightly so that the trigger unit is triggered.

3. Pull the trigger unit [2] forwards slightly.



4. Turn the trigger unit 180°.

Tool: open-end spanner WAF8




5. Push the trigger unit back into the shaft straight until it clicks into place.



ATTENTION Incorrect installation of the trigger unit may cause property damage!

If the door lever handle is used before the trigger unit has clicked into its final position, the lock may be damaged.


- ▶ Push the trigger unit back into the shaft straight until it clicks into place.
- ▶ Only use the door lever handle once the trigger unit has clicked into place.



Adjusting the trigger unit → *from page 114*

5.8.3 Preparing to connect Eneo to the power supply

1. Insert the cable (type E, EZ or cable junction for lengthways installation).



Additional accessories → *from page 71* and connection to access control systems → *from page 102*.



5.8.4 Multipoint lock

1. Insert the multipoint lock [1] into the leaf groove.
2. Fasten the multipoint lock with screws [2].




INFO

Do not occupy the screw positions for day-time unlocking.



INFO

Turn in screws straight → *from page 28*.




5.8.5 Lever-operated espagnolette, standard (second opening leaf)

5.8.5.1 Variable locking pattern


The lever-operated espagnolette, standard with locking pattern V02/03 is adaptable. The lever-operated espagnolette, standard can be machined to adapt it to locking patterns V02/01, V02/05 and V02/07.

The diagram below shows the individual markings where the lever-operated espagnolette, standard can be adapted.





5.8.5.2 Overview of locking patterns



[A] Cropping

Pattern	Min. SRH	Max. SRH
V02/05	1615	1930
V02/01	1931	1974
V02/03	1975	2214
V02/07	2215	2430
V02/03 + extension 600	2485	2784
V02/03 + extension 800	2785	3000


5.8.5.3 Installation

1. Insert the lever-operated espagnolette, standard [1] into the leaf groove.
2. Fasten the lever-operated espagnolette, standard with screws [2].



INFO


Fill every screw position. Turn in screws straight.
→ from page 28





5.8.6 Lever-operated espagnolette Plus (second opening leaf)

5.8.6.1 Overview of locking patterns



[A] Cropping

Pattern	Min. SRH	Max. SRH
V02/05	1760	1900
V02/01	1901	2070
V02/03	2071	2270
V02/07	2271	2590
V02/03 + extension 468	2520	2700
V02/03 + extension 768	2820	3000


5.8.6.2 Installation

1. Insert the lever-operated espagnolette Plus [1] into the leaf groove.
2. Fasten the lever-operated espagnolette Plus with screws [2].



INFO

Fill every screw position. Turn in screws straight.
→ from page 28






5.8.7 Door lever handle set



INFO

When an original cylinder is not installed, only lock and unlock the door using the universal access key.



INFO

Install the profile cylinder or round cylinder without subjecting it to stress and align at a right angle to the leaf.




INFO

When changing the profile cylinder or round cylinder, choose a faceplate screw length based on the back-set.


Profile cylinder

1. Insert the profile cylinder [1] and fasten with a screw [2].



Round cylinder

1. Insert the round cylinder [1] and fasten with a screw [2].



Door lever handle set with long plate and escutcheon




INFO

Fit long plates and escutcheons without subjecting them to stress.

1. Fit the door lever handle set with long plate and escutcheon according to the hardware manufacturer's specifications.

- [1] Long plate
- [2] Screw for long plate
- [3] Cover for long plate
- [4] Door lever handle
- [5] Escutcheon
- [6] Screw for escutcheon
- [7] Cover for escutcheon
- [8] Pull handle





5.9 Frame


5.9.1 Striker strip / striker

1. Insert the striker strip [1] or striker [3] into the frame.
2. Fasten the striker strip or striker with screws [2].



INFO


Fill every screw position. Turn in screws straight.
→ from page 28



5.9.2 Variable striker strips

Striker strips with locking pattern V02/03 are adaptable. The variable striker strip can be machined to adapt it to locking pattern V02/01 or V02/05.

The diagram below shows the individual markings where the striker strip can be adapted.





5.9.3 Installation

Fasten the striker strip or strikers with the recommended screw type (Ø4).



INFO


Do not use stainless-steel screws on the Roto Sil surface.

Use stainless-steel screws (type A2) on stainless-steel components.




INFO

The screw length depends on the profile used.



5.9.4 Shootbolt protrusion striker

1. Fasten the shootbolt protrusion striker [1] with two screws [2].






6 Accessories

6.1 Cable junction


6.1.1 Overview of versions

Version 1 – rebate clearance 12 / 16 mm


Mat. no. 820187



Mat. no. 820255




Installation situation




- [1] Frame component
- [2] Leaf component
- [3] Cover plate

Version 2 – rebate clearance 4 / 12 mm


Mat. no. 820187



Mat. no. 820194



Installation situation



- [1] Frame component
- [2] Leaf component
- [3] Retaining bracket
- [4] Cover plate




Version 3 – rebate clearance 12 / 16 mm


Mat. no. 817028



Mat. no. 820255




Installation situation




- [1] Frame component
- [2] Leaf component

Version 4 – rebate clearance 4 / 12 mm


Mat. no. 817028



Mat. no. 820194



Installation situation




- [1] Frame component
- [2] Leaf component
- [3] Retaining bracket




6.1.2 Bush and connector

Schematic diagram of bush



Cable: LIF9Y11Y, 6 x 0.25 mm²

Schematic diagram of connector



Cable: LIF9Y11Y, 6 x 0.25 mm²


6.1.3 Processing instructions

- Due to the large number of profiles and hardware variants on the market, it is not possible to make any generally applicable statements about installation, because some of the dimensions of these systems differ.
- Before starting installation, inspect the installation location and the available space in the rebate area.
- Installation location: door frame or door rebate
- Prevent torsion (twisting of the cable) along the entire length of the cable, specifically in the metal spring.
- Drill holes for routing the cable Ø 16. Deburr the drill holes and remove swarf.
- In addition to the generally applicable rules of good engineering practice, the following technical regulations must be complied with, in particular: VDS 2311, VDE 0100.


6.1.4 Dimensions

Frame components

Frame side without power supply unit




Frame side with power supply unit






Sash components

Sash side without casing (lengthways installation)



Sash side with casing (U-shape)



6.1.5 Drilling and routing dimensions



INFO

The drill holes must be free from burr and swarf.




INFO

Only tighten screws by hand.


Recommendation: predrill screw holes.

Frame component without power supply unit + leaf component without casing



[1] Routing depth: 30 mm

Frame component without power supply unit + leaf component with casing




[1] Routing depth: 60 mm

[2] Routing depth: 1 mm



Frame component with power supply unit + leaf component without casing




[1] Routing depth: 42 mm

[2] Routing depth: 3 mm

[3] Routing depth: 30 mm

Frame component with power supply unit + leaf component with casing



[1] Routing depth: 42 mm

[2] Routing depth: 3 mm

[3] Routing depth: 60 mm

[4] Routing depth: 1 mm

6.1.6 Installation

1. Carry out the routing and drilling work → *from page 78*.



INFO

Only turn in screws by hand.

Predrilling the screw holes is recommended.

2. Route the cable [1] through the leaf or frame.
Lay a cable loop, ensuring that there is enough spare cable.




INFO

Do not crush or damage the cable when installing the frame.




3. Fasten the mounting box with screws [2].

Leaf side



4. **Frame side**



5. Fasten the connector side with a screw.

6. Hinge the leaf and establish the plug connection.



ATTENTION
Property damage due to short-circuit.


Chips in the connector or bush may cause a short-circuit.

- Keep the connector and bush clean.




INFO

Note the anti-twist protection of the plug connection.





7. Fasten the plug connection with a screw [3].



8. Check that the cable junction with built-in power supply unit is working properly → *from page 83*.



INFO

Do not exceed the technical values (voltage, current, power) → *from page 124*.



INFO

Only an electrician may connect the frame component with built-in power supply unit (mat. no. 817028) to the 230 V power supply.



DANGER

Risk of death caused by electric shock!

Current can lead to fatal injuries.

- ▶ Take extra care when handling live components.
- ▶ Only an electrician may connect the power supply unit to the mains voltage.
- ▶ Observe and comply with the respective national regulations (in Germany VDE 0100 and others).

6.1.7 Performance test for cable junction with built-in power supply unit

1. Connect the mains cable to the 230 V power supply.



INFO

Only an electrician is permitted to establish the connection to the 230 V power supply.

2. Check the power supply at the power supply unit.
LED is lit up green when there is voltage.

6.1.8 Fault assistance

Fault	Cause	Corrective action	To be carried out by
No power supply.	Loose plug connection.	Plug in the connector so that it is secure.	■
	Cable breakage.	Replace the cable.	■
	No power connection.	Check the plug connections. Check the power supply (LED must be lit). Check the power supply unit.	■

□ = May be carried out by a specialist company or the end user

■ = **Must** be carried out by a specialist company

6.1.9 Dismantling

1. Stop the power supply. Pull out the connector.
2. Undo and remove the screw.
3. Undo the plug connection with a hex key or suitable screwdriver.



ATTENTION

A faulty spring may cause property damage.

Undoing the plug connection in an uncontrolled manner may damage the spring.


- ▶ Do not pull on the spring to undo the plug connection.
- ▶ Use a hex key or suitable screwdriver to undo the plug connection.

4. Unhinge the sash.
5. Protect the plug connection against dust and moisture.




6.2 Finger scan

6.2.1 Dimensions



6.2.2 Routing and drilling dimensions



[1] Main lock backset

[2] Above lower edge of leaf



6.2.3 Installation



INFO


When laying the cables, ensure that the black box is installed such that it can be easily accessed for maintenance (for example near the drive unit routing).




INFO

Ensure that the cable is not damaged during installation. Lay the cable in the glass rebate if possible.


1. Connect the cable [1] (Plug&Play);
install the cable loop [2].



2. Insert the housing [3] into the routing.
3. Fasten with two screws [4].



4. Fit the cover [5].





INFO

The finger scan and black box come as a pair. If the finger scan is changed, the black box always has to be replaced as well.

6.2.4 Testing using the autotest function

Automatic testing mechanism for testing the cabling and connections with the motor lock. It is not necessary to calibrate the master or user fingerprints.

⇒ Only possible in the delivery state.

Autotest function	LED
Finger scan is ready for operation.	● ●
Remote control: press the 0 button.	○ ●
Confirm with OK .	● ○
Autotest is started automatically	
The cabling, pairing, encryption and connections are tested	
Autotest successful (after approx. 10 seconds).	● ○



INFO

The autotest is limited to a total of ten cycles, with one cycle already having been performed in the production plant.

6.2.5 Overview



- [1] Green LED
- [2] Red LED
- [3] Blue LED
- [4] Sensor



Remote control



Notes

- There is no access control when delivered. Any person can be calibrated and therefore open the door.
- When delivered, all LEDs are continuously lit (when connected correctly).
- Storage capacity up to 150 fingerprints.
- Wait for around three minutes during initial use or after a power failure (settings are retained).
- The latent fingerprint is removed automatically after each use. This prevents misuse.
- After each use, the latent fingerprint is removed and the sensor surface is cleaned automatically. Additional cleaning with water or chemical cleaning agents is not necessary. Cleaning agents may damage the sensor.
- The mobile device (smartphone, etc.) is only used as a display. User details (log files, fingerprints, etc.) are only saved locally in the finger scan. Data is not saved over Wi-Fi, in the cloud or on external storage devices (e.g. smartphones). This means that the security of the main door is not put at risk if a mobile phone is lost.
- Mobile devices do not have to be explicitly registered, but instead are reauthenticated each time a connection is established.
- The sensitivity of the finger scan can be configured via the BioKey® app. This may be necessary for the elderly or children.

6.2.6 Definitions

Master fingerprint (e.g. left index fingerprint)

Calibrate and delete user fingerprints.

The master fingerprint cannot be used to open doors.

User fingerprint (e.g. right index fingerprint)

Opens the door.

6.2.7 Calibrating the master fingerprint



INFO

Master fingerprints are for management purposes only and are not for opening the door. Different fingerprints must be used for the master fingerprint and user fingerprint.

Master fingerprint = management

User fingerprint = open door



INFO

Wash your hands and apply hand cream before calibrating master / user fingerprints.

Calibrating the master fingerprint	LED
Finger scan is in the factory settings state.	 
Move the master finger over the sensor.	
Repeat this process at least six times.	
The LEDs light up each time.	
The master fingerprint is calibrated.	 
Finger scan is ready for operation.	 



INFO

During the calibration process, if a finger has been moved over the sensor and not accepted as the master fingerprint, the green and red LEDs will remain lit.

Repeat the calibration process.

Once the master fingerprint is calibrated, the device is ready for operation.

Only the blue LED is lit.

User fingerprints are calibrated via the BioKey® app.

6.2.8 BioKey® app



INFO

In the delivery state, the master fingerprint has to be calibrated first **before** opening the app.

A BioKey® app is available for Android and iOS operating systems.





BioKey® app



- 1. Download the BioKey® app.
- 2. Install the BioKey® app on a mobile device (such as smartphone, tablet, etc.).
- 3. Activate Bluetooth on your mobile device and enter your location when prompted.

6.2.9 Calibrating user fingerprints



INFO

Wash your hands and apply hand cream before calibrating master / user fingerprints.

⇒ The BioKey® app is installed on the mobile device.

Calibrating user fingerprints	LED
Open the BioKey® app.	
Activate Bluetooth.	
Tap on the BioKey® app and select a device.	
Move the master finger over the sensor.	○ ○
Or	● ●
Enter the master code ^[1] using the remote control. Confirm with OK .	○ ○
Select User in the menu.	
Add a user (+) and assign a name.	
Add fingerprint.	
Calibrating a new fingerprint	● ○
The number of inputs appears on the display.	
The LED lights up green: OK	
The LED lights up red: repeat the process.	
The fingerprint is calibrated.	  3x ○ ○

Calibrating the master fingerprint via the BioKey® app

Master fingerprints can also be calibrated via the BioKey® app.

To do so, first move the slider in the BioKey® app to **Master user**.

For the calibration steps, see *Calibrating user fingerprints*.

[1] The master code label is located on the remote control, in the product leaflet and on the black box.

6.2.10 Blocking or approving user fingerprints

Blocking users

- 1. Open the BioKey® app and pair it.
- 2. Select **User** in the menu.
- 3. Select the user.
- 4. Slide the slider to **Block user**.

Approving users

- 1. Open the BioKey® app and pair it.
- 2. Select **User** in the menu.
- 3. Select the user.
- 4. Slide the **Block user** slider back.

6.2.11 Reset

Deleting an individual user

(user fingerprint / master fingerprint)

- 1. Open the BioKey® app.
- 2. Select the **User** menu.
- 3. Select the user that is to be deleted.
- 4. Tap **Delete**.

Deleting all users

⇒ Master code (reset code): 6-digit code, see remote control.

⇒ Close the BioKey® app and deactivate Bluetooth.

Remote control

Deleting all users	LED
Press the DA button.	 
Enter the master code.	 
The green LED flashes each time a button is pressed.	
Confirm with OK .	  3x  

The finger scan has returned to the factory settings state (red, green and blue LEDs are continuously lit).

6.2.12 Changing the master code



INFO

For security reasons, change the master code after commissioning.

Remote control

- 1. Press the **D** button.
- 2. Press the **E** button.
- 3. Enter the old code.
- 4. Confirm with **OK**.
- 5. Enter a new 6-digit master code.
- 6. Confirm with **OK**.
- 7. Repeat the new 6-digit master code.
- 8. Confirm with **OK**.

BioKey® app



1. Open the BioKey® app.
2. Select the **Settings** menu.
3. Select **Reset code**.
4. Enter a new 6-digit master code.



INFO

Note down the new code in your own documents; no replacement will be provided in the event of loss.

6.2.13 Opening the door

1. Move the user finger over the sensor.
2. The door is unlocked.

6.2.14 Fault assistance


Fault	Cause	Corrective action	To be carried out by
User fingerprint was not accepted.	Same fingerprint calibrated as for the master and user fingerprint.	Use a different fingerprint than the user fingerprint.	☐
	The user fingerprint is blocked.	Approve the user fingerprint in the app.	☐
Could not connect to the BioKey® app	No authentication.	Enter master code using the remote control.	☐
		Move the master finger over the sensor.	☐
	No location approval for the app.	Approve the location for the app in the smartphone settings.	☐
User name or access attempts are not displayed correctly.	Power supply to the finger scan was interrupted.	Close the BioKey® app then restart it.	☐

☐ = May be carried out by a specialist company or the end user

☒ = **Must** be carried out by a specialist company


6.3 4in1 access control system

6.3.1 Dimensions





6.3.2 Routing and drilling dimensions



[1] Main lock backset

[2] Above lower edge of leaf


6.3.3 Installation



INFO

The power supply unit must not be connected to the power supply yet.

1. Carry out the routing.
2. Clean the surface with alcohol.
With textured coatings, the surface has to be slightly roughened and a primer additionally has to be applied.
3. Pull the protective film [1] off the double-sided adhesive tape.




4. Thread the cable [2] through the routed hole.
Connect the outdoor unit [3] and black box to the cable.



INFO

For installation in the wall, the black box must be fitted in the secured area. This prevents it being tampered with from the outside.





5. Insert the 4in1 access control system into the door leaf or the wall and adhere it.

**INFO****Sealing**

Press down on the 4in1 access control system evenly on all sides.

Additional sealing is recommended for textured surfaces.

6.3.4 Testing using the autotest function

Automatic testing mechanism for testing the cabling and connections with the motor lock.

Commissioning using the app is not necessary.

There is no limit on the number of tests.

⇒ Only possible in the delivery state.

1. Enter code 123456 on the display.

2. Confirm by checking the box.

⇒ The door opens.

6.3.5 Reset (factory settings)

Black box

The black box is located indoors, where it is protected. Press the Reset button on the indoor unit (approx. 3 seconds) until two signals are emitted in quick succession.

SOREX SmartLock app

Via the first calibrated user in the app: Settings -> "Delete".

Note the device's range.

6.3.6 SOREX SmartLock app

The settings for 4in1 access control system can be controlled using an app.

An app is available for Android and iOS operating systems.



6.3.7 Fault assistance

Fault	Cause	Corrective action	To be carried out by
Keypad code was not accepted.	Keypad code is blocked	Before entering the code, press the "X" key on the code keypad to delete the numbers that were previously entered.	☐
	Keys on the 4in1 access control system have previously been pressed.		
After multiple incorrect codes have been entered, the keypad will stop responding.	If an incorrect code has been entered five times, the keypad will be blocked for 5 minutes.	Wait until the blocking time has elapsed.	☐

☐ = May be carried out by a specialist company or the end user

☒ = **Must** be carried out by a specialist company



6.4 Hand-held transmitter

6.4.1 Overview



INFO

Only relevant to the wireless version.



Each button [1] on the hand-held transmitter can be used for different Eneo units.

Two Eneo units can be controlled separately using a single hand-held transmitter.

It is possible to calibrate both buttons on a single Eneo unit.

Up to 30 hand-held transmitters or hand-held transmitter buttons can be calibrated on the Eneo A radio receiver.



INFO

The radio receiver has a specific code. The receiver will only accept the signals from the transmitter if the codes of the radio receiver and the hand-held transmitter match.


6.4.2 Security



INFO

Protect the hand-held transmitter against unintentional operation.

1. Push the protective cap [1] over the buttons [2].



6.4.3 Calibrating the hand-held transmitter




PRECONDITION

The following is required to calibrate a hand-held transmitter:

- Thin stick with a max. diameter of 3 mm to actuate the calibration push-button on Eneo A
- Hand-held transmitter
- Eneo A

1. Unlock and open the door.
2. Press the radio calibration push-button [1] on Eneo A.
A sequence of sounds lasting up to 18 seconds is heard.
Eneo A is in calibration mode.



3. Activate the hand-held transmitter (within 18 seconds).
Once Eneo A has detected the signal from the hand-held transmitter, at this point it stops the sequence of sounds and confirms the detected signal with a beep lasting 2 seconds.
Eneo A exits calibration mode automatically.
4. If you need to calibrate additional hand-held transmitters, repeat steps 3 and 4.

6.4.4 Deleting hand-held transmitters



INFO

It is not possible to delete individual hand-held transmitters.

1. Unlock and open the door.
2. Press and hold the radio calibration push-button for at least 10 seconds.
Once Eneo A has detected the signal from the radio calibration push-button, it will confirm this with two beeps which sound in quick succession.
All calibrated hand-held transmitters are deleted.
Eneo A exits calibration mode automatically.



6.4.5 Changing the battery

1. Undo three screws on the back.
2. Open the housing.
3. Insert a new battery. Ensure that the polarity is correct.



ATTENTION
Incorrect disposal may pollute the environment.

- Leaking battery acid may pollute the environment.
- ▶ Do not dispose of the battery in household waste.
 - ▶ Observe the national regulations on the disposal of batteries.

4. Fit the housing and secure with three screws.

6.4.6 Fault assistance

Fault	Cause	Corrective action	To be carried out by
The hand-held transmitter LED flickers or does not light up when a button is pressed.	Battery too weak or flat.	Replace the batteries of the hand-held transmitter.	☐
The motor lock is not working when a button on the hand-held transmitter is pressed.	Hand-held transmitter not calibrated or fault during calibration.	Repeat the calibration process for the hand-held transmitter on the motor lock.	☐
Calibration push-button was actuated but calibration / deletion is not possible (4x beeps).	The lock is not in the correct position.	With the door open, lock the lock using the key.	☐
	Max. number of hand-held transmitters or buttons has been reached.	Delete the hand-held transmitter and recalibrate any hand-held transmitters that are still required.	☐

☐ = May be carried out by a specialist company or the end user

☒ = **Must** be carried out by a specialist company

7 Connection diagram

The following diagrams are non-binding application examples.

These are only intended to provide guidance for customers and do not represent customer-specific solutions.

Proper operation is the responsibility of the customer.

The customer is obligated to ensure safe installation, use, maintenance and operation. The customer is furthermore obligated to ensure that the equipment is only installed by a qualified electrician; failure to do so may result in a risk of fire or risk of electric shock.

Compliance with the applicable standards and provisions must be ensured at all times; the company installing the system bears full responsibility for this.

The system must not be operated if compliance with the applicable standards and provisions cannot be ensured.

No guarantee is given for the application examples provided. Roto Frank Fenster- und Türtechnologie GmbH shall assume no liability for damage caused by use of the application examples, unless we are obligated to bear liability in accordance with legal provisions in cases of wilful intent.




INFO

Installation and maintenance work may only be carried out by a company specialising in electrical systems. There is a risk of death when using a mains voltage of 230 V (or 120 V). Only carry out work when the power supply is disconnected.

The following basic circuits are used as examples. See IMO 310 for other connections.



7.1 Control Unit



Connector / cable assignment

White: IN1 / input 1 (OPEN)

Brown: +24 V


Green: GND

Yellow: unassigned

Grey: unassigned

Pink: unassigned

7.2 Cable junction without power supply unit





Connector / cable assignment

White: IN1 / input 1 (OPEN)

Brown: +24 V


Green: GND

Yellow: unassigned

Grey: unassigned

Pink: unassigned

7.3 Cable junction with built-in power supply unit





ATTENTION

Property damage due to short-circuit

If the power supply unit is connected to the 230 V power supply before the cable junction is connected, this may cause a short-circuit.

- ▶ On the leaf side, connect the cable for the cable junction to the cable junction. For the cabling, see the connection diagram.
- ▶ On the frame side, connect the cable for the cable junction, e.g. to the push-button, intercom, etc.

Connector / cable assignment

White: IN1 / input 1 (OPEN)

Brown: +24 V

Green: GND

Yellow: unassigned

Grey: unassigned

Pink: unassigned

Finger scan cable assignment (between JST connector and black box)

Brown: +24 V


Yellow: GND

Green: control system (OPEN)

7.4 Cable routing

Cable – type E

Inside




[1] Flush-mounted box

Connection for Eneo Control Unit.

Power supply unit: installation in control cabinet

[2] Cable junction with cable – type E


Outside



[3] Push-button


Cable – type EZ

Inside



- [1] Flush-mounted box
Connection for Eneo Control Unit.
Power supply unit: installation in control cabinet
- [2] Cable junction with cable – type EZ

Outside



- [3] Push-button
- [4] Access control system

7.5 Cable lengths

Maximum cable lengths for Eneo cable junction without power supply unit in conjunction with Eneo A, plug-in 180°, incl. 4 m cable.

Up to 8 m	Up to 18 m	Up to 24 m	Up to 36 m	Up to 60 m
0.34 mm ²	0.75 mm ²	1 mm ²	1.5 mm ²	2.5 mm ²



INFO

In the case of a cable junction with built-in power supply unit, the cable for the power supply connection must have three poles and a cable cross section of at least 1.5 mm².




8 Adjustment



INFO

Roto hardware components may only be adjusted by authorised professionals when the element is installed.

8.1 Overview



Assignment	Description	
[1]	Combination striker	→ from page 109
[2]	Latch / deadbolt striker	→ from page 109
[3]	Shootbolt protrusion striker	→ from page 109
[4]	Connector component for lever-operated espagnolette Plus	→ from page 112
[5]	Cover bridge	→ from page 112

8.2 Strikers




INFO

The adjustment principles are shown here by way of example. The component shown may differ from the figure depending on the type (latch / deadbolt, combination, automatic, etc.) and profile system (timber / PVC / aluminium). The adjustment principles remain the same.

8.2.1 Latch / deadbolt striker

1. Undo the retaining screws [1].

Tool: T20 hexalobular socket screwdriver



2. Perform lateral adjustment ± 2 mm by hand. Lock-in position integrated in component.

3. Tighten the retaining screws.

Tool: T20 hexalobular socket screwdriver

8.2.2 Combination striker

1. Perform lateral adjustment ± 1.5 mm via the adjustment eccentrics [1] at the top and bottom.


Tool: size 3 hex key



INFO


The adjustment distance of 1.5 mm is reached after a 90° turn:

- 90° turn = 1.5 mm
- 80° turn = initial position
- 270° turn = -1.5 mm
- 360° turn = initial position








8.2.3 Timber

	Latch / deadbolt	Combination	Shootbolt protrusion	Bolt
Adjustment of lock-in position ± 2 mm		-	-	-
Eccentric adjustment ± 1.5 mm				
Eccentric adjustment (with a retaining screw in the centre) ± 1.5 mm	-		-	-
Turning the component	-	-	-	

8.2.4 PVC


	Latch / deadbolt	Combination	Shootbolt protrusion	Bolt
Eccentric adjustment ± 1.5 mm				

8.2.5 Aluminium

	Latch / deadbolt	Combination	Shootbolt protrusion	Bolt
Eccentric adjustment ± 1.5 mm				

8.3 Striker strips

2 combination lockings (2C)




4 combination lockings (4C)




[1] Eccentric adjustment
 ± 1.5 mm

8.4 Lever-operated espagnolette, standard



[1] Eccentric adjustment
 ± 1.5 mm

8.5 Lever-operated espagnolette Plus



[1] Eccentric adjustment
 ± 1.5 mm




Shootbolt protrusion

1. Adjust the adjusting screw [1] for shootbolt protrusion [2] at the top and bottom.

Adjustment distance ± 1.5 mm

Tool: size 3 hex key



INFO

For information about integrating a threshold, refer to [IMO_423](#) (Roto Eifel).


8.6 Trigger unit



PRECONDITION

The trigger unit has previously been triggered.

1. Measure the functional clearance.



2. Measure the projection [Y] of the trigger unit.




INFO


The optimum projection [Y] is calculated as follows:

Functional clearance + min. 2.5 mm

Roto delivery state: projection approx. 8.5 mm




3. Push the pin [1] (Ø max. 3 mm) into the inspection opening.



4. Push the pin down slightly so that the trigger unit is triggered.



5. Pull the trigger unit [2] forwards slightly.



6. Adjust the trigger unit projection.


Tool: open-end spanner WAF8



INFO

1 turn (360°) = 0.5 mm

Projection max. 9 mm



7. Push the trigger unit back into the shaft straight until it clicks into place.



ATTENTION

Incorrect installation of the trigger unit may cause property damage!

If the door lever handle is used before the trigger unit has clicked into its final position, the lock may be damaged.

- ▶ Push the trigger unit back into the shaft straight until it clicks into place.
- ▶ Only use the door lever handle once the trigger unit has clicked into place.

8. Carry out a performance test:

- ▶ Close the door leaf.
- ▶ It must be possible to turn the key in the locking direction.

9 Commissioning and operation

9.1 E700

9.1.1 Initial operation of the door



DANGER

Risk of death caused by electric shock!

Current can lead to fatal injuries.

- ▶ Installation and maintenance work may only be carried out by qualified electricians.
- ▶ Observe and comply with the respective national regulations (in Germany VDE 0100 and others).
- ▶ When laying the network connection cable on-site, all-pole safety isolation must be established.
- ▶ Only carry out work when the power supply is disconnected.

Before connecting Eneo A to the supply voltage, check that it is working properly, as for a mechanical multipoint lock. The force required to actuate the lever handle and the cylinder key must not exceed normal manual force.

9.1.1.1 Mechanical-automatic performance test

Fixing screws



ATTENTION

Over-tightened screws may cause property damage!

Over-tightened screws lose their hold and no longer provide the necessary strength.

- ▶ Do not over-tighten screws. Note the torque.

Use a screwdriver to check that all fixing screws have been tightened.


Door lever handle function

Push the door lever handle all the way down and release.

- ▶ The door lever handle must automatically return to the initial position.

Automatic function

1. Press the trigger unit.



- ▶ All of the automatic power wedges and the deadbolt extend.
2. Retract the automatic power wedges and deadbolt again using the door lever handle or cylinder key. To do so, push the door lever handle all the way down and release.
- ▶ All of the automatic power wedges and the deadbolt retract again.

**Latch function**

1. Push the door lever handle all the way down.
 - ▶ The latches must retract.
 - ▶ When pushed down, the latches may protrude over the lock faceplate by a maximum of 2 mm.
2. Release the door lever handle.
 - ▶ The latches must extend fully.
3. Turn the key in the profile cylinder in the unlocking direction.
 - ▶ The latches must retract fully.
4. Turn the key in the profile cylinder to the initial position.
 - ▶ The latches must extend fully.

Blocking function

Automatic power wedges and the deadbolt in the main lock are push-back safeguarded without using the key.

1. Press the trigger unit.
 - ▶ All of the automatic power wedges and the deadbolt extend.
2. Turn the key in the profile cylinder in the locking direction.
 - ▶ The door lever handle is blocked.
 - ▶ It must be possible to remove the key.
3. Turn the key in the profile cylinder in the unlocking direction.
 - ▶ The door lever handle can be operated.
4. Retract the automatic power wedges and deadbolt again using the door lever handle or cylinder key.

For fault assistance, see → *from page 119*.

**INFO**

Carry out a mechanical-automatic performance test again after the door has been installed.

9.1.1.2 Electrical performance test

Performance test for cable junction without power supply unit, with Eneo Control Unit

1. Connect the Eneo Control Unit to the cable junction cable → *from page 102*.
2. Insert the power supply unit for the Eneo Control Unit.
 - Green LED (power): indicates that operating voltage is present.
 - OPEN button: drive receives the opening signal; door unlocks.
3. Close the door: the door locks automatically.

Performance test for cable junction with built-in power supply unit

1. Connect the mains cable to the 230 V power supply.



INFO

Only an electrician is permitted to establish the connection to the 230 V power supply.

2. Check the power supply at the power supply unit.
LED is lit up green when there is voltage.

Performance test using access control system

Finger scan → *from page 88*


4in1 access control system → *from page 97*

Hand-held transmitter → *from page 100*

For fault assistance, see → *from page 119*.

9.1.2 Activating / deactivating acoustic signals

1. Unlock and open the door.
2. Press and hold the radio calibration push-button [1] for 25 – 30 seconds.
Eneo A provides confirmation of the following events:
 - Activation of the acoustic signals with a long beep.
 - Deactivation of the acoustic signals with two beeps which sound in quick succession.Eneo A exits the mode automatically.





9.1.3 Fault assistance

9.1.3.1 Mechanical-automatic

Check the tolerances and height offset on the element. → *from page 22*

Fault	Cause	Corrective action	To be carried out by
The lock does not lock automatically.	Screws are too tight.	Loosen the screws.	■
	Screws are too long.	Use the recommended screw length.	■
	Screws scrape against the connecting rod.	Turn in screws straight or use screws with a partial thread (without a thread behind the screw head).	■
	Projection of the trigger unit not large enough.	Adjust the trigger unit. → <i>from page 114</i>	■
	Connecting-rod guides at an angle.	Straighten the connecting-rod guides.	■
	Screw positions for day-time unlocking occupied.	Do not occupy the screw positions for day-time unlocking. → <i>from page 59</i>	■
The door lever handle is not in the zero position (hanging).	Escutcheon fitted incorrectly (escutcheon not at the correct angle).	Remove the escutcheon and attach with drilling jig.	■
	Spindle-receiver holding spring worn / broken.	Replace the lock casing.	■
	Friction between door lever handle and long plate too high.	Lubricate.	□
The door lever handle is not in the zero position (too high).	Square spindle bent.	Replace the entire square spindle or the entire door lever handle set.	■
The locking lug of the profile cylinder scrapes in the main lock casing.	Long plate / escutcheon and door lever handle / door lever handle not positioned correctly in relation to one another (axes and interaction on the inside and outside).	Remove the escutcheons and long plate and secure with drilling jig (drill new holes if required).	■
Lock rattles in the door.	Screws are too loose.	Tighten the screws according to the specifications.	■
The lock casing deadbolt scrapes in the striker plate.	Frame and frame components twisted in the vertical axis.	Free up space for the deadbolt by mechanically machining the striker plate.	■
The door does not stay closed.	The latches do not run in.	Adapt the frame component position.	■
	The door has dropped / warped.	Adjust the door hinges and frame components, provide new spacer blocking for the door element if required (see Glazing Guide FLY_11). Adjust the electrical openers.	■
The door cannot be closed.	The latch is not running into the lock casing.	Lubricate the latch with Roto adhesive grease.	□
	Contamination in the threshold area.	Clean the threshold area.	□

□ = May be carried out by a specialist company or the end user

■ = **Must** be carried out by a specialist company

9.1.3.2 Electronic

E700 – Eneo A

Fault	Cause	Corrective action	To be carried out by
System not functioning. Eneo A not responding, no beeps.	There is no 230 V voltage on the primary side of the power supply unit.	Have electrical installation work carried out by qualified personnel only, as described in the installation instructions.	■
	There is no 24 V voltage on Eneo A.	Check the 24 V terminal contacts on the power supply unit. Check the supply line between the power supply unit and Eneo A, and replace if necessary.	■
	There is 24 V voltage on Eneo A but the polarity is the wrong way round.	Swap round the power supply on the secondary side of the power supply unit.	■
	No signal at the signal transmitter output or no signal at the Eneo A input. Or The drive is in a final position and does not receive a signal to implement a movement.	Check whether voltage is being supplied. Check the wiring → <i>from page 102</i> . Check whether the hand-held transmitter is calibrated → <i>from page 100</i> . Check whether the access control system is connected and set correctly → <i>from page 94</i> .	■
	Still not working?	Disconnect the voltage, wait for 10 seconds and restart it. Carry out a test using the Eneo Control Unit → <i>from page 118</i> . Contact qualified personnel.	■
Eneo A does not unlock fully. 3x two-tone beeps	Connecting rod or Eneo A is blocked, e.g. by being previously locked using the key.	Unlock the door using the key.	■
	Door gasket compression is too high.	Adjust the door → <i>from page 109</i> .	■
	Additional lock or main lock blocks the drive. Foreign object blocks the connecting rod.	Remove the foreign object.	■
	Door lever handle operated or load placed on the door during the unlocking process.	Open the door again and wait until Eneo A has fully unlocked the door.	□
Eneo A does not unlock fully. 4x two-tone beeps	Eneo A does not reach its final position.	Replace Eneo A	■
Eneo A does not lock automatically. 4x two-tone beeps	Eneo A does not reach its final position.	Replace Eneo A	■

Cable junction

Fault	Cause	Corrective action	To be carried out by
No power supply.	Loose plug connection.	Plug in the connector so that it is secure.	■
	Cable breakage.	Replace the cable.	■
	No power connection.	Check the plug connections. Check the power supply (LED must be lit). Check the power supply unit.	■

Finger scan

Fault	Cause	Corrective action	To be carried out by
User fingerprint was not accepted.	Same fingerprint calibrated as for the master and user fingerprint.	Use a different fingerprint than the user fingerprint.	□
	The user fingerprint is blocked.	Approve the user fingerprint in the app.	□
Could not connect to the BioKey® app	No authentication.	Enter master code using the remote control.	□
		Move the master finger over the sensor.	□
	No location approval for the app.	Approve the location for the app in the smartphone settings.	□
User name or access attempts are not displayed correctly.	Power supply to the finger scan was interrupted.	Close the BioKey® app then restart it.	□



4in1 access control system

Fault	Cause	Corrective action	To be carried out by
Keypad code was not accepted.	Keypad code is blocked	Before entering the code, press the "X" key on the code keypad to delete the numbers that were previously entered.	☐
	Keys on the 4in1 access control system have previously been pressed.		
After multiple incorrect codes have been entered, the keypad will stop responding.	If an incorrect code has been entered five times, the keypad will be blocked for 5 minutes.	Wait until the blocking time has elapsed.	☐

Hand-held transmitter

Fault	Cause	Corrective action	To be carried out by
The hand-held transmitter LED flickers or does not light up when a button is pressed.	Battery too weak or flat.	Replace the batteries of the hand-held transmitter.	☐
The motor lock is not working when a button on the hand-held transmitter is pressed.	Hand-held transmitter not calibrated or fault during calibration.	Repeat the calibration process for the hand-held transmitter on the motor lock.	☐
Calibration push-button was actuated but calibration / deletion is not possible (4x beeps).	The lock is not in the correct position.	With the door open, lock the lock using the key.	☐
	Max. number of hand-held transmitters or buttons has been reached.	Delete the hand-held transmitter and recalibrate any hand-held transmitters that are still required.	☐

☐ = May be carried out by a specialist company or the end user

☒ = **Must** be carried out by a specialist company


9.1.4 Acoustic signals

Sound	Type of message	Meaning
	Confirmation	Command understood, process completed correctly.
	Note	Command understood, Eneo A cannot carry out command. Maximum number of cycles (approx. 6 –8 locking and unlocking procedures per minute) in time unit exceeded. Eneo A is ready for operation again after 30 – 40 seconds.
	Note	Calibration push-button was pressed but calibration / deletion is not possible.
	Fault	Automatic calibration not successful.
	Fault	Control unit detected excess current in the motor and stopped.
	Fault	The final position of the connecting rod was not reached in the maximum permitted time of 3 seconds.
	Note	Command from hand-held transmitter is executed but the hand-held transmitter battery will soon be flat.

9.2 Lever-operated espagnolette, standard

Unlocking the second opening leaf

1. Fold out the lever at the side as far as the latching point.
2. Open the second opening leaf.




Locking the second opening leaf

1. Close the second opening leaf.
2. Push the lever down and fold it in.

9.3 Lever-operated espagnolette Plus

Unlocking the second opening leaf

1. Fold out the lever.
2. Open the second opening leaf.





Locking the second opening leaf

1. Close the second opening leaf.
2. Fold in the lever.

10 Technical data

10.1 Eneo A

Technical data	
Power supply	24 V DC ($\pm 5\%$), 2.5 A, SELV output voltage according to EN 62368-1, EN 60335-1
Continuous current consumption	25 mA
Current consumption	1.5 A (peak 2.0 A)
Relative air humidity	$\leq 93\%$
Temperature range	During operation: -25 to $+60$ °C During transport: -25 to $+70$ °C
Output relay load	Max. 40 mA, free-wheeling diode for inductive load present internally
Standards	EN 60335-1, EN 60335-2-103 Low Voltage Directive complied with CE conformity

10.2 Cable junction

Technical data for power supply unit Cable junction 817028	
Cable	H03VV-F 3x1.5 mm ²
Input	230 V AC; 50 – 60 Hz
Output	24 V DC; 2.5 A DC
Degree of protection in accordance with DIN 40050	IP67 (when inserted and only the plug connection between leaf and frame)
Temperature range	When idle: -10 °C to $+70$ °C When moving: -10 °C to $+50$ °C
Standards	CE conformity

10.3 Finger scan

Technical data	
Dimensions of outdoor unit (W x H x D)	44.6 x 75.4 x 29.0 mm
Finger scan sensor	Touch chip line sensor No latent fingerprints after use > 2 million uses
Operating voltage	8 to 24 V DC
Power consumption	Approx. 1 W
Relay data	24 V DC 500 mA (max.)
Temperature range	During operation: -20 to $+85$ °C
Relative air humidity	Up to 95%
IP rating	IP65 (outdoor use)
ESD performance	16 kV
Storage capacity	Up to 150 fingerprints
Fingerprint recording time	Approx. 1 second
Fingerprint identification time	Approx. 10 ms per comparison
False rejection rate (FRR)	Approx. 0.5%
False acceptance rate (FAR)	Between 0.00001 and 0.000001 (at – FRR 0.5%)
Switching duration	3 seconds
Standards	CE conformity



10.4 4in1 access control system

Technical data	
Dimensions of outdoor unit (W x H x D)	55 x 99.8 x 19.8 mm
Operating voltage	12 V – 24 V DC, 200 mA
Relay data	1 A, 24 V DC switching capacity
Temperature range	During operation: –20 to +60 °C
IP rating	IP66 (with waterproof bonding)
Storage capacity	100 fingerprints 150 numerical codes 200 RFID media (Mifare classic transponder) Unlimited eKeys
Encryption	AES 128 bit
Standards	CE conformity

10.5 Hand-held transmitter

Technical data	
Hand-held transmitter	Up to 30 hand-held transmitters or hand-held transmitter buttons can be paired with the Eneo CC radio receiver
Radio receiver	Fitted in the drive unit
Security system	66 bit encoding and rolling code system Every single unlocking process takes place with a new, automatically assigned code; access cannot be gained through playing back a recorded code.
Frequency	433.92 MHz
Radio range	10 metres with a clear view of the door and full battery.
Radio licence for the following countries	A, B, CH, D, DK, E, F, FIN, GB, GR, I, IRL, IS, L, LT, N, NL, P, S, CZ
Battery	Type 27 A (12 V)
Standards	CE conformity

10.6 Power supply unit

Technical data	
Dimensions of outdoor unit (W x H x D)	78.0 x 93.0 x 56.0 mm
DC voltage	24 V (output)
Rated current	2.5 A (output)
Voltage adjustment range	21.6 to 26.4 V (output)
Voltage range	88 to 264 V AC, 124 to 370 V DC (input)
Frequency range	47 to 63 Hz (input)
Temperature range	Operation: –20 to +60 °C
Relative air humidity	Up to 20 - 90%
Standards	CE conformity

11 Maintenance



CAUTION

Performing maintenance work incorrectly can lead to injuries.

Performing maintenance incorrectly can lead to injuries.

- ▶ Ensure that there is sufficient space for installation before starting work.
- ▶ Ensure that the installation site is clean and tidy.
- ▶ Always have hardware adjustment and replacement work performed by a specialist company.
- ▶ Secure the sash against unintentionally opening or closing.
- ▶ Do not unhinge the sash for maintenance.



ATTENTION

Incorrect or improper testing may cause property damage.

Incorrect or improper testing of the hardware may cause the element to malfunction.

- ▶ Have the hardware checked by a specialist company when installed.
- ▶ If defects need to be remedied, have the element unhinged and remounted by a specialist company.



INFO

The manufacturer must draw the attention of builders and end consumers to these maintenance instructions.

Roto Frank Fenster- und Türtechnologie GmbH recommends the manufacturer conclude a maintenance agreement with their end users.

No legal claims can be derived from the following recommendations; their application is to be based on the specific individual case.

	Responsibility	
Maintenance interval	☐	→ from page 126
Cleaning		→ from page 127
Clean hardware	☐	
Care		→ from page 128
Lubricate movable parts	☐	
Lubricate locking points	☐	
Performance test		→ from page 129
Check that hardware components are fitted securely	☐	
Inspect hardware components for wear	☐	
Check that movable parts work properly	☐	
Check that locking points work properly	☐	
Check ease of movement	☒	
Repair		→ from page 131
Retighten screws	☒	
Replace damaged components	☒	

☐ = May be carried out by a specialist company or the end user

☒ = **Must** be carried out by a specialist company

11.1 Maintenance intervals



ATTENTION

Failure to adhere to maintenance intervals may cause property damage.

The maintenance interval for all tasks relating to the hardware components is **annually** at the least. In hospitals, schools and hotels, the maintenance interval is **six-monthly**.

Regular maintenance is necessary in order to maintain the proper and smooth-running operation of the hardware and to prevent premature wear or even defects.

- ▶ Determine and adhere to the appropriate maintenance interval in accordance with the ambient conditions.



11.2 Cleaning



ATTENTION

Using incorrect cleaning agents and sealing compounds may cause property damage.

Cleaning agents and sealing compounds may damage the surfaces of components and gaskets.

- ▶ Do not use aggressive or flammable liquids, acidic cleaners or abrasive cleaners.
- ▶ Only use mild, pH-neutral cleaning agents that have been diluted.
- ▶ Apply a thin protective film to the components, for example using a cloth soaked in oil.
- ▶ Avoid aggressive vapours (e.g. produced by formic acid, acetic acid, ammonia, amine compounds, ammonia compounds, aldehyde, carbolic acid, chlorine, tannic acid) around the element.
- ▶ Do not use any acetic acid-crosslinking or acid-crosslinking sealing compounds or those with the aforementioned constituents as both direct contact with the sealing compound and its fumes can corrode the surface of the components.

Cleaning the hardware

- ▶ Remove deposits and contaminants from the hardware using a soft cloth.
- ▶ Lubricate the latches and trigger unit after cleaning → 11.3 "Care" from page 128.
- ▶ Apply a thin protective film to the hardware, for example using a cloth soaked in oil.




ATTENTION

Contamination may cause property damage.

Contamination may get behind the floating mullion and block the multipoint locking system.

- ▶ Do not wipe contamination in the upper area of the sash (e.g. plaster, gypsum) towards the floating mullion.



11.3 Care



ATTENTION

Using incorrect lubricants may cause property damage.

Substandard lubricants can prevent the hardware from working properly.

- ▶ Use high-quality lubricants.
- ▶ Only use resin-free and acid-free lubricants.
- ▶ Use appropriate lubricant in more challenging climatic conditions. Note the manufacturer specifications.



ATTENTION

Cleaning agents and lubricants may pollute the environment.

Leaking or excess cleaning agents and lubricants may pollute the environment.

- ▶ Remove any leaking or excess cleaning agents and lubricants.
- ▶ Dispose of cleaning agents and lubricants separately and properly.
- ▶ Observe the applicable directives and national laws.

Ease of movement can be improved by lubricating or adjusting the hardware. Lubricate the latches and trigger unit at least once a year.

Recommended lubricants


- Roto NX / NT grease



INFO

The figure displays the positioning of potential lubrication points. The figure does not necessarily match the installed hardware. The quantity of lubrication points varies depending on the size and design of the element.

11.3.1 Lubrication points



[1] Grease

Lubricate the latches and trigger unit at least once a year.



ATTENTION

Using incorrect lubricants may cause property damage.

Substandard lubricants can prevent the hardware from working properly.

- ▶ Use high-quality lubricants.
- ▶ Only use resin-free and acid-free lubricants.
- ▶ Use appropriate lubricant in more challenging climatic conditions. Note the manufacturer specifications.



ATTENTION

Incorrect lubrication may cause property damage!

Lubricants in the main lock and additional locks may prevent them from working properly.

- ▶ Only lubricate the latches and trigger unit.



11.4 Drive unit



INFO

The Roto Eneo A drive unit requires no maintenance. Repairs may only be performed by a specialist company.

11.5 Performance test



PRECONDITION

The leaf and frame must be vertical for the performance test.

11.5.1 Mechanical-automatic performance test

Fixing screws



ATTENTION

Over-tightened screws may cause property damage!

Over-tightened screws lose their hold and no longer provide the necessary strength.
► Do not over-tighten screws. Note the torque.

Use a screwdriver to check that all fixing screws have been tightened.


Door lever handle function

Push the door lever handle all the way down and release.

- The door lever handle must automatically return to the initial position.

Automatic function

1. Press the trigger unit.



- All of the automatic power wedges and the deadbolt extend.
2. Retract the automatic power wedges and deadbolt again using the door lever handle or cylinder key. To do so, push the door lever handle all the way down and release.
- All of the automatic power wedges and the deadbolt retract again.

Latch function

1. Push the door lever handle all the way down.
- The latches must retract.

- ▶ When pushed down, the latches may protrude over the lock faceplate by a maximum of 2 mm.
- 2. Release the door lever handle.
 - ▶ The latches must extend fully.
- 3. Turn the key in the profile cylinder in the unlocking direction.
 - ▶ The latches must retract fully.
- 4. Turn the key in the profile cylinder to the initial position.
 - ▶ The latches must extend fully.

Blocking function

Automatic power wedges and the deadbolt in the main lock are push-back safeguarded without using the key.

- 1. Press the trigger unit.
 - ▶ All of the automatic power wedges and the deadbolt extend.
- 2. Turn the key in the profile cylinder in the locking direction.
 - ▶ The door lever handle is blocked.
 - ▶ It must be possible to remove the key.
- 3. Turn the key in the profile cylinder in the unlocking direction.
 - ▶ The door lever handle can be operated.
- 4. Retract the automatic power wedges and deadbolt again using the door lever handle or cylinder key.

For fault assistance, see → *from page 119*.



INFO

Carry out a mechanical-automatic performance test again after the door has been installed.



11.5.2 Electrical performance test

Performance test for cable junction without power supply unit, with Eneo Control Unit

1. Connect the Eneo Control Unit to the cable junction cable → *from page 102*.
2. Insert the power supply unit for the Eneo Control Unit.
 - Green LED (power): indicates that operating voltage is present.
 - OPEN button: drive receives the opening signal; door unlocks.
3. Close the door: the door locks automatically.

Performance test for cable junction with built-in power supply unit

1. Connect the mains cable to the 230 V power supply.



INFO

Only an electrician is permitted to establish the connection to the 230 V power supply.

2. Check the power supply at the power supply unit.
LED is lit up green when there is voltage.

Performance test using access control system

Finger scan → *from page 88*

4in1 access control system → *from page 97*

Hand-held transmitter → *from page 100*

For fault assistance, see → *from page 119*.

11.6 Repair



WARNING

Improper repair work may pose a risk of death!

Improper maintenance may prevent the element from working properly and make it less safe to use.

- ▶ Always have repairs performed by a specialist company.



ATTENTION

Improper screw fixings may cause property damage.

Loose or faulty screws can prevent the hardware from working properly.

- ▶ Check that the individual screws are secure and seated correctly.
- ▶ Tighten or replace loose or faulty screws.
- ▶ Use only the suggested screws.

Repair work includes replacing and repairing components and is only necessary if components have become damaged after wear or as a result of external circumstances. The hardware must be secured reliably in order to ensure that the element works properly and is safe to use.

The following tasks must only be performed by a specialist company:


- All adjustment work on the hardware,
- Replacing hardware or hardware components,
- Installing and removing windows, doors or balcony doors

The specialist company must observe the following:


- Perform the necessary repair work properly, according to generally recognised engineering practice and in accordance with the applicable regulations.
- Do not perform makeshift repairs on worn or damaged components.
- Only use original or approved spare parts for repairs.

11.7 General information


11.7.1 For the end customer




When the lock is extended, do not close the door or push it against the frame.




Do not paint over the lock or locking components (latch, deadbolt, additional lock, etc.).




Do not place heavy loads on the handle; the maximum load is 15 kg.



Do not carry the leaf by the door lever handle.



Where there are visible signs that force has been used, replace the lock and/or handle.



[1] Grease

Lubricate the latches and trigger unit at least once a year.



ATTENTION

Using incorrect lubricants may cause property damage.

Substandard lubricants can prevent the hardware from working properly.

- ▶ Use high-quality lubricants.
- ▶ Only use resin-free and acid-free lubricants.
- ▶ Use appropriate lubricant in more challenging climatic conditions. Note the manufacturer specifications.



ATTENTION

Incorrect lubrication may cause property damage!

Lubricants in the main lock and additional locks may prevent them from working properly.

- ▶ Only lubricate the latches and trigger unit.

12 Dismantling



WARNING

Improper dismantling may pose a risk of death!

The sash may fall during dismantling.

- ▶ Secure the sash to prevent it from falling, e.g. by using two people.
 - ▶ Always have dismantling work performed by a specialist company.
-



CAUTION

Physical strain may cause injury and damage to health.

Carrying and lifting heavy loads for extended periods leads to physical injury in the long term.

- ▶ When carrying or lifting loads, maintain an ergonomically correct posture. The maximum permissible load is 25 kg for men and 10 kg for women.
-



INFO

Unless otherwise stated, dismantling is performed in reverse order to installation.

12.1 Hardware components

Removing hardware components

1. Undo the fixing screws.
2. Remove the hardware components.
3. Dispose of the hardware components properly.



13 Transport

13.1 Transporting elements and hardware



DANGER

Improper transport poses a risk of death!

Improper procedures for transporting, loading or unloading elements may cause serious injuries and glass breakage as a result of the elements swinging open, falling or becoming overloaded.

- ▶ Note the applicable accident prevention regulations.
- ▶ Note force application points and reaction forces.
- ▶ Prevent the sash from opening uncontrollably.
- ▶ Avoid jerky movements.
- ▶ Use suitable transportation means and protective devices.
- ▶ Watch out for protruding components.
- ▶ Transport heavy loads with two people and use suitable transportation means (such as an industrial truck).



CAUTION

Trapped limbs may result in injuries.

The transported goods can skid, open, close or fall during transportation tasks. This can result in limbs being trapped and seriously injured.

- ▶ Never reach near the scissor stays.
- ▶ Close the sash after installation and secure it in place for transport.
- ▶ Wear safety gloves and protective footwear.



CAUTION

Physical strain may cause injury and damage to health.

Carrying and lifting heavy loads for extended periods leads to physical injury in the long term.

- ▶ When carrying or lifting loads, maintain an ergonomically correct posture. The maximum permissible load is 25 kg for men and 10 kg for women.

Hardware is supplied to the specialist company as complete sets. The components are packaged accordingly for each scope of delivery. The instructions for safely transporting the hardware are described below.

Observe the following basic instructions when transporting hardware:

- ▶ Transport larger scopes of delivery using appropriate transportation means (such as industrial trucks).
- ▶ Note the transport weight in order to select appropriate transportation means.
- ▶ Ensure that the transport process is careful and appropriate for the material and that components are protected against dirt during transport.
- ▶ Immediately check the delivery for completeness and transport damage on receipt.



INFO

Submit a complaint about any defects as soon as they are identified. Claims for damages may only be made within the reclamation period.

Use the following transportation means for support when transporting, loading and unloading larger scopes of delivery:

- Industrial trucks, e.g. forklifts, telescopic handlers, pallet trucks
- Lifting equipment, e.g. transport nets, carry straps, round slings
- Protective devices, e.g. edge protection, spacer blocks



INFO

Industrial trucks and lifting devices may only be operated by qualified persons.




INFO


Lifting equipment and protective devices may only be used if they are in full working order.

13.2 Information on transport


- During transport, secure the leaf against the frame using suitable supports (run-up blocks, wedges, etc.).



- Do not carry the leaf by the door lever handle.



- Transport the multipoint lock vertically. If transporting it horizontally, always support it at two points. Do not bend the connecting rod.



13.3 Storing the hardware

Store all hardware components as follows until they are installed:

- Dry and protected
- On a level surface
- Protected against sunlight

14 Disposal



ATTENTION

Incorrect disposal may pollute the environment.

Pieces of hardware are raw materials.

- ▶ Dispose of hardware for environmentally friendly material re-utilisation as mixed scrap.

14.1 Disposing of packaging

The hardware is supplied as complete sets together with the packaging. Once unpacked, the installation company or builder is responsible for disposing of the packaging properly. The packaging materials are produced in accordance with current environmental protection standards. The materials can be recycled separately.

Follow the basic instructions below for the proper disposal of packaging:

- ▶ Do not dispose of packaging in household waste.
- ▶ Hand over packaging at local waste collection points or recycling centres.
- ▶ Observe the national regulations on the disposal of recyclable materials.
- ▶ Contact the local authorities if necessary.

14.2 Disposing of hardware

Once the hardware is finished with, the end user or builder is responsible for properly disposing of the windows, doors or balcony doors and the hardware, including any accessories. Hardware is produced in accordance with current environmental protection standards. The materials can be recycled separately.

Follow the basic instructions below for the proper disposal of hardware:

- ▶ Observe the information and specifications for disposal contained in the other applicable documents.
- ▶ Separate hardware components from windows, doors or balcony doors.
- ▶ Do not dispose of hardware in household waste.
- ▶ Hand over hardware at local waste collection points or recycling centres.
- ▶ Observe the national regulations on the disposal of recyclable materials.
- ▶ Contact the local authorities if necessary.

14.3 Batteries

Disposal of batteries in accordance with the legal provisions of the individual countries, for instance in accordance with EU directives (2006/66/EC: Directive on batteries and accumulators and waste batteries and accumulators).

According to the Battery Ordinance (BattV) in Germany, used batteries must not be disposed of in household waste; they must be taken to an appropriate disposal site.



14.4 Electronic waste

Disposal of electronic waste in accordance with the legal regulations in the individual countries, e.g. in accordance with EU directives (2002/95/EC: Directive on the restriction of the use of certain hazardous substances in electrical and electronic equipment, RoHs and 2002/96/EC: Requirements for the



take-back and recycling of waste electrical and electronic equipment (WEEE)).

According to the Federal Electrical and Electronic Equipment Act (ElektroG) in Germany, waste electronic equipment must not be disposed of in household waste; it must be taken to an appropriate disposal site.



15 Additional information


15.1 Product information about E700 – 2AH

Classification key

prEN 15685:2019	3	S	7	0	0	C	3	0	0	3
-----------------	---	---	---	---	---	---	---	---	---	---

Purpose of use	Yes / No	Comments (additional information for the purpose of classification)	Reference
On Turn-Only leaf doors	Yes	Multipoint locks are tested for their lateral forces and counter force.	
Lock with spring-loaded feature	Yes	Tested in accordance with 5.5.1 and 5.11.3 using tensioning devices 23 and 32 and/or in accordance with 5.11.5 or 5.11.6 using tensioning device 35 with spring-loaded feature.	
Lock without spring-loaded feature	Yes	Tested in accordance with 5.5.1 and 5.11.3 using tensioning devices 22 and 31 and/or in accordance with 5.11.5 or 5.11.6 using tensioning device 34 without spring-loaded feature.	
Suitable for use on smoke protection doors	No	See manufacturer declaration regarding a test in accordance with EN 1634-3 or the details of the melting point of the relevant latch components or the duration of proven smoke resistance, if applicable.	
Suitable for use on smoke protection and fire protection doors	No	See manufacturer declaration regarding a test in accordance with EN 1634-1 or the details of the melting point of the relevant latch components or the duration of proven smoke / fire resistance, if applicable.	
Multipoint lock for use with door lever handle without spring-loaded feature	Yes	Lock must comply with 4.1.7, minimum self-aligning torque of the lock nut 0.8 Nm.	
Multipoint lock for use with door lever handle with spring-loaded feature	No	Manufacturer declaration regarding self-aligning torque.	
Use of locks which are locked from the inside (when the key needs to be operated from the inside in order to get out)	Yes	It must not be possible to remove burglar inhibiting components from the inside of the multipoint lock without special tools.	



	No.	Locking point Item 7	Anti-jemmy protection point Item 9	Door closing point Item 10	With spring-loaded feature / Without spring-loaded feature
	[1]	3	3	0	With spring-loaded feature
	[2]	3	0	0	With spring-loaded feature
	[3]	3	3	0	With spring-loaded feature



**From a single source.
Optimum hardware systems to meet all challenges.**

Window

Hardware systems for windows and balcony doors

Sliding

Hardware systems for large sliding windows and doors

Door

Matching hardware technology everything about doors

Equipment

Additional technology for windows and doors



Contact

