

Replacing the Water Filter

The in-reservoir charcoal filter reduces chlorine taste and fine particulates. Replace it every two months, or sooner if the brew develops an off taste.

- Remove the reservoir and pour out any remaining water.
- Lift the old filter out of its housing at the bottom of the reservoir. Discard with household waste.
- Rinse the new filter under cold running water for 15 seconds to flush loose carbon dust.
- Press the new filter firmly into the housing until it clicks into place.
- Refill the reservoir with fresh water and reinsert it. Run one full reservoir through the brew circuit to flush the new filter before the next shot.
- Record the replacement date so the next change is easy to schedule.

